

Formulate Designer Series 20' Backwall - Kit 02

FMLT-DS-20-02

Formulate® Designer Series 20ft displays have unique stylistic features and shapes, are portable and easy to assemble. The aluminum tube frame features snap-buttons and/ or spigot connections and zipper pillowcase fabric graphics. All displays come in portable, wheeled transit cases. Simply pull the pillowcase fabric graphic(s) over the frame and zip.



features and benefits:

- Premium aluminum tube frames with snap button/ spigot assembly
- Easy to store and ship
- Quick to set up
- Weighted feet for added stability
- Two zipper pillowcase fabric graphics
- Center wall features extrusion frame, LED lights and push-fit fabric graphics
- Lifetime limited hardware warranty against manufacturer defects

dimensions:

Hardware	Graphic
<p>Assembled unit: 230" w x 96" h x 40" d 5845mm(w) x 2438mm(h) x 1015mm(d)</p> <p>Approximate weight with cases: 190 lbs / 86.2 kgs</p>	<p>Refer to related graphic template for more information.</p> <p>Visit: www.exhibitors-handbook.com/graphic-templates</p>
<p>Shipping</p> <p>Packing case(s): 1 OCH 2 OCE-2</p> <p>Shipping dimensions: OCH: 12" l x 26" h x 50" d 304mm(l) x 661mm(h) x 1270mm(d)</p> <p>Shipping dimensions: OCE-2: Expandable case length (l) may vary 40" - 66" l x 18" h x 18" d 1016mm-1677mm(l) x 458mm(h) x 458mm(d)</p> <p>Approximate total shipping weight (includes cases & graphics): 212 lbs / 96.2 kgs</p>	<p>additional information:</p> <p>Graphic material: dye-sublimation zipper pillowcase fabric</p> <p>Frame A and B stand independently of one another, no connection hardware required.</p>


We are continually improving and modifying our product range and reserve the right to vary the specifications without prior notice. All dimensions and weights quoted are approximate and we accept no responsibility for variance. E&OE. See Graphic Templates for graphic bleed specifications.

Included In Your Kit


Tools, Components,
& Connectors




HEX KEY SET x1




ES50-1 x10




ES50-2W x2



ES30 x8




LN114-SCRW x2




PLT-BP-LN114-S2-650 x2


Graphics



FMLT-DS-20-02-A x1




FMLT-DS-20-02-B x1




FMLT-DS-20-02-OP-LN x1

Included In Your Kit

Tubes



FMLT-DS-20-02-A-T1 x2




FMLT-DS-20-02-A-T2 x2




FMLT-DS-20-02-A-T3 x4



FMLT-DS-20-02-A-T4 x2



FMLT-DS-20-02-A-T6 x4



FMLT-DS-20-02-A-T7 x4





FMLT-DS-20-02-A-T8 x1



FMLT-DS-20-02-A-T9 x1

Labeling Diagram

FMLT-DS-20-02




Frame A and B stand independently of one another, no connection hardware required.

Connection Methods


Formulate™ structures use a number of different yet simple connection methods. Your kit will include one or more of the connection methods shown below. Steps within the Kit Assembly will reference a specific method for each connection point.

Connection Method 1: ES30 / ES50 / ES75




Compress the unlocked connector and slide one tube onto each end. Lock both screws carefully using your hex key tool. Be sure to lock securely, but do not overtighten.

Connection Method 2: Snap Buttons & Swage




Locate the snap button on the connector or swage tube. Locate the hole on the corresponding tube. Press the snap button with your thumb and slide the tube and connector together so that the snap button snaps fully into the lock hole. To disassemble, press the snap button and pull apart.

Connection Method 3: ES30-90B / ES30-I / ES30-C



Compress one unlocked end of the connector and slide it through one tube end. Compress the other end of the connector and slide the second tube on. Lock both screws carefully using your hex key tool. Be sure to lock securely, but do not overtighten.

Connection Method 4: Tube Clamps



Be sure to fully assemble all frames before using clamps. With the clamp unlocked, place one tube of the first frame into the mouth of the clamp. Place the second tube (if applicable) into the second mouth of the clamp. With both frame's tubes in the clamp, be sure to lock securely, but do not overtighten.


Kit Assembly

Step by Step

Step 1.



Locate the components necessary for assembling Frame A. Assemble your frame in order according to the Labeling Diagram.

Please reference Connection Methods 1, 2 and 3 for more details.



Step 2.

Fit graphic A onto Frame A. For ease of installation, pull the fabric cover over the top of the frame while the frame rests flat on the floor. Zip to enclose.



Step 3.

Locate the PLT-BP-LN114-S2-650's and LN114-SCRW's. With the provided hex key set tool, fasten the base plates onto the bottom ES50-2W connectors of Frame A.

Setup Complete.

